



BOWDRY – Instructions for use

1. Ensure the Bowdry is complete, including a discharge bung on the chassis and that the handle is secured with 2 x star wheels.
2. Adjust the pressure of the roller onto the foam drum so that the foam is compressed by only about 25% (one quarter). Do not over tighten the roller, this will make the Bowdry harder to push and increase foam wear. **NOTE** the roller bar is **NOT** preset to avoid foam indentation.
3. Push the Bowdry forward through the water to be removed. The foam will be more efficient as it becomes saturated. The Bowdry can be operated with the back wheels on or off the ground.
4. To manoeuvre the Bowdry tilt back onto the rear wheels. On very soft ground the Bowdry can be turned carefully on the foam roller.
5. When not collecting water, always push the Bowdry on the rear wheels only, to avoid foam damage.
6. To empty the Bowdry, use the side discharge point, remembering to replace the bung when drained.
7. To clean the Bowdry, stand on its side and remove loose debris (stones, leaves, grit etc) then lightly hose the complete machine. **Note**-do not use a pressure washer on the foam.
8. To store the Bowdry, leave on its side to drain & slacken off roller bar if left for a prolonged period. Do not leave upright when foam is wet, this will leave a `flat spot`.
9. New foam kits and spare parts are available from your supplier.
10. **Health & Safety.** Do not overfill the Bowdry so that it becomes too heavy to push with comfort. **Never** try to lift the Bowdry when full.